

### Description

Service kit including one cleaning liquid, one lubricant and two cloths. Compatible with all of X2's columns.

It is recommended to perform maintenance every six months to remain the good qualities of the lift, or if the product is exposed to any chemicals or cleaning agents.



### Instructions

1. Extract the telescopic lift as much as possible.
2. Clean the lower segments of the telescopic lift with the cleaner fluid, applied on the blue cloth.
3. Apply a thin layer of the lubrication fluid on the lower segments of the telescopic column by using the white cloth.
4. Drive the telescopic column up and down three times.